



Version 1.1 15.09.2014

Cleaning and Maintenance

Polarex Wall Armour

Pre Cleaning: Before cleaning, all surfaces must be free of any dust (use a vacuum to clear away any dust). This ensures that there are no scratches to the surface when cleaning. Ensure that there is no fat residue or film in place as this can equate to colour change under the influence of UV light.

Adhesive Leak: If there is any unhardened adhesive remaining it must be removed from the surface immediately with a suitable cleaner. If however the adhesive has hardened then it is generally only mechanically possible to remove and could potentially damage the surface.

Cleaning: We recommend weekly cleaning of the surface to prevent any build-up of fat residue and dust. Before the commencement of cleaning ensure all surfaces are fat residue and dust free to prevent any scratches from forming. Use a soft cloth to wipe the surface along with using a neutral cleaning agent to gently clean.

For high traffic areas, soiling and marks: We recommend regular (daily) cleaning of these areas with a soft cloth and the use of a neutral cleaning agent.

Please note: **Do not** use any abrasive cleaners, pads or wire wall. **Do not** exceed the temperature of 60 C when cleaning any Polarex Products.